

OIL SEAL CROSS REFERENCE

TRAILER AXLE OIL SEALS										
Inner Bearing	Stemco				CR SKF Scotseal			Dana	National	
	Guardian	Grit Guard	Voyager	Discover	Classic	Plus	Plus XL	OutRunner	Standard	Gold Five Star
663	307-0713	372-7098	373-0113	373-0213	40136	40129	40129	850	370036A	380036A
665A	307-0744	372-7095	373-0144	---	43752	43753	47754	853	370037A	380037A
HM218248	307-0743	372-7097	373-0143	373-0243	46305	46304	46300	859	370025A	380025A
HM518445	307-0723	372-7099	373-0123	373-0223	42623	42622	42627	851	370065A 376590A	380065A 386590A

FRONT AXLE OIL SEALS										
Inner Bearing	Stemco				CR SKF Scotseal			Dana	National	
	Guardian	Grit Guard	Voyager	Discover	Classic	Plus	Plus XL	OutRunner	Standard	Gold Five Star
HM212049, 641, H715345	308-0853	---	383-0153	---	44922	44919	44916	855	370124A	---
H715345	308-0856	---	383-0156	---	45103	45102	45095	857	370131A	380131A
6461A	308-0864	382-8064	383-0164	383-0264	43764	43763	43761	863	370048A	380048A
HM212044, HM212047, HM212049, 39581	308-0836	382-8036	383-0136	383-0236	35066	35059	45058	847	370001A	380001A

DRIVE AXLE OIL SEALS										
Inner Bearing	Stemco				CR SKF Scotseal			Dana	National	
	Guardian	Grit Guard	Voyager	Discover	Classic	Plus	Plus XL	OutRunner	Standard	Gold Five Star
580, 582	309-0903	392-9094	393-0103	393-0203	45099	45093	45093	856	370022A	380022A
598A, 594A	309-0960	392-9132	---	---	48000	480001	48002	860	370005A	---
594, 594A, 598, 598A	309-0973	392-9131	393-0173	393-0273	47697	47695	47692	861	370003A	380003A
683, 681A	309-0970	392-9087	---	---	47699	---	---	---	370006A	---
47686	309-0915	392-9099	393-0112	393-0212	38750	38748	38746	848	370024A	---
47685, 47686, 47678, 5760	309-0912	392-9099	393-0112	393-0212	38780	38779	38776	849	370023A	380023A
663, HM516449, HM516449A	309-0904	392-9112	393-0104	393-0204	42672	42671	42673	852	370031A	380031A